

Settings: Nokia 5230 Nuron

Version 4

créé par [tmo_donovan](#) le 23 févr. 2012 16:14, dernière modification effectuée par [tmo_tim](#) le 29 mars 2013 15:26

Table of contents

- [Table of contents](#)
- [Backlight](#)
 - [Brightness](#)
 - [Duration](#)
- [Device information](#)
 - [Phone Help](#)
 - [My Nokia](#)
 - [User Forum](#)
 - [My Account](#)
 - [Backup](#)
 - [Software version](#)
 - [Update software](#)
- [Device login](#)
 - [Log in with existing account](#)
 - [Log in with new account](#)
 - [Sidekick registration](#)
- [Network](#)
 - [Airplane mode](#)
 - [Browser message \(WAP Push\)](#)
 - [Change band](#)
 - [Data roaming](#)
 - [Manual network selection](#)
- [Reset](#)
 - [Back Up Information Before a Reset](#)
 - [Master Reset](#)
 - [Master Reset using the Hardware buttons](#)
 - [Restore Information After a Reset](#)
- [Soft Reset](#)
- [Security](#)
 - [Change - SIM PIN code](#)
 - [Lock - SIM PIN](#)
 - [Change - Security code \(aka lock code\)](#)
 - [Lock - Application lock](#)
 - [Lock - Keypad](#)
 - [Lock - Phone](#)
 - [Unblock - PIN \(PUK Code\)](#)
 - [Unblock - SIM \(SIM subsidy unlock\)](#)
- [Time and date](#)
 - [Alarm clock - Set](#)
 - [Auto-update \(NITZ\)](#)
 - [Time / date - Set](#)

Backlight

Brightness

How to change or adjust the display option for brightness

To raise or lower the screen brightness, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.

4. Double-tap **Display**.
5. Double-tap **Brightness**.
6. Touch and drag the bar to the desired brightness level.

Duration

How to change, increase, or decrease the backlight duration

To increase or decrease the amount of time before the backlight dims, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.
4. Double-tap **Display**.
5. Double-tap **Light time-out**.
6. Touch and drag the bar to the desired duration level.

[Back to top](#)

Device information

Phone Help

How to access the Help menu

To access Help on your phone, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Applications**.
3. Tap **Help** or **Phone Help** for additional tips and tricks.

My Nokia

How to access My Nokia

My Nokia is a free service that you can sign up to receive tips and support information about your phone, as well as important updates from T-Mobile and latest information on Nokia products, services, and accessories.

When you first turn your phone on, tap **Accept** at the Welcome to My Nokia screen and follow instructions on the screen to complete the sign up process. You can also go to <http://my.nokia.com/mynokiausa/registration> to sign up online.

To access My Nokia, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Applications**.
3. Tap **Help**.
4. Tap **My Nokia**.

User Forum

How to access the user forum menu

To access the user forum on your phone, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Applications**.
3. Tap **Help**.
4. Tap **User Forums**.

My Account

How to access My Account

To access My Account, from the Home screen, tap the **My Account** icon to view the following information:

- **Billing summary**
- **Pay your bill**
- **Plan & services**
- **Purchase Callertunes**

Backup

Options available for back up on the Nokia 5230 Nuron include the following:

- All
- Settings
 - Device and preference settings (i.e. Themes, Backgrounds, Profiles)
- Messages
- Contacts
- Calendar entries
- Bookmarks
 - Web Bookmarks
- Files
 - Images
 - Sounds
 - Videos
- Repeat backup
 - Never
 - Daily
 - Weekly

To back up your data on your memory card, follow these steps:

1. From the Home screen, select **Menu**.
2. Scroll to and select **Applications**.
3. Scroll to and select **Office**.
4. Select **File Manager**.
5. Select **Backup**.
6. Select **Options**.
7. Select **Back up now**

Software version

How to check the software version

To find the software version on your phone, follow these steps:

1. From the Home screen, tap the **Dialer** icon.
2. Enter ***#0000#** to view phone information.

Update software

To update the software version on your phone, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Applications**.
3. Tap **SW Update**.

[Back to top](#)

Device login

Log in with existing account

We're sorry, but this feature is not available on your particular phone model.

Log in with new account

We're sorry, but this feature is not available on your particular phone model.

Sidekick registration

We're sorry, but this feature is not available on your particular phone model.

[Back to top](#)

Network

Airplane mode

How to turn on or turn off airplane mode

Airplane mode turns off the wireless radio. This allows you to use programs while traveling on an airplane, but not make or receive calls. To turn or airplane mode, follow these steps:

1. Briefly press the **Power** key.
2. Tap **Offline**.

Browser message (WAP Push)

WAP Push messages are supported.

Turning off WAP Push messages is not supported on your particular phone model.

Change band

We're sorry, but this feature is not available on your particular phone model.

Data roaming

How to use, turn on, or turn off data roaming

To use, turn on, or turn off data roaming, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Connectivity**.
4. Double-tap **Data transfer**.
5. Tap **Sync**.
6. Tap **Options**.
7. Tap **Advanced settings**.
8. Tap **Sync when roaming**.
9. Tap **Never allow**.
10. Tap **OK**.

Manual network selection

How to perform a manual network selection to register on a network

Related error: 'Network unavailable'

To manually select the wireless network the phone connects to, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Connectivity**.
4. Tap **Network**.
5. Tap **Operator selection**.
6. Tap **Manual**.

Note: The phone detects and registers on wireless networks inside T-Mobile's calling area, but roaming networks are usually restricted to T-Mobile SIM cards. You can manually select a network only in areas where T-Mobile does not own GSM spectrum.

[Back to top](#)

Reset

Back Up Information Before a Reset

To back up all data or information, follow these steps:

1. From the Home screen, select **Menu > Applications > Office > File manager**.
2. Press **Backup** twice.
3. Select **Backup contents**.
4. Select from the following items you want to back up: e.g.
 - **Messages**
 - **Contacts**
 - **Calendar entries**
 - **Bookmarks & Files**
5. DO NOT select Settings (as this may cause issues to repeat during a master reset).
6. Select **Ok**.
7. Select **Options > Back up now > Yes**.

Master Reset

How to perform a master reset

A master reset restores the original factory settings and will erase the following content stored on the phone memory:

- Text messages
- Picture messages
- Pictures
- Videos
- Bookmarks
- Java games

A master reset will erase Java games on the memory card but it will not delete pictures and videos.

1. Back up all necessary data on the internal memory.
2. From the Home screen, tap the **Dialer** icon.
3. Enter ***#7370#**.
4. Enter the default code **12345**.
5. Tap **Yes** to accept.

Master Reset using the Hardware buttons

To master reset the device, follow these steps:

1. Power off the device. (This next step is easier if the device is placed on a flat surface)
2. Place the phone on a flat surface to easily be able to press the Send, End and Camera button with one hand.
3. With the other hand press the Power button until the phone vibrates.
4. Release the Power button.
5. When the Nokia logo goes away you can let go of remaining buttons.

Restore Information After a Reset

Restore all data or information, follow these steps:

1. From the main menu, select **Applications > Office > File manager**.
2. Press **Backup** twice.
3. Select **Options > Restore**.
4. Select from the following items you want to restore: e.g.
 - Messages
 - Contacts
 - Calendar entries
 - Bookmarks & Files
5. Select **Ok**.
6. Verify that the device turns off and then back on once the restore is completed.

[Back to top](#)

Soft Reset

We're sorry, but this feature is not available on your particular phone model.

[Back to top](#)

Security

Change - SIM PIN code

How to change the default SIM PIN code

To change the default SIM PIN code, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.
4. Double-tap **Phone mgmt**.
5. Double-tap **Security**.

6. Tap **Phone and SIM card**.
7. Double-tap **PIN code**.
Note: PIN code request must be turned **ON** to continue.
8. Enter the PIN.
9. Tap **OK**.
10. Enter the new PIN.
11. Tap **OK**.
12. Re-enter the new PIN to confirm.
13. Tap **OK**.

Lock - SIM PIN

How to turn on or turn off the SIM PIN code

The SIM PIN code is used to protect the SIM from being used in other phones. When you enable the SIM PIN code, the phone prompts you to enter the code after turning it on. To turn on or turn off the SIM card lock, follow these steps:

To lock

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.
4. Double-tap **Phone management**.
5. Double-tap **Security**.
6. Double-tap **Phone and SIM card**.
7. Double-tap **PIN code request**.
8. Double-tap **On**.
9. Enter the PIN code. The default is **1234**.
10. Tap **OK**.

To unlock

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.
4. Double-tap **Phone management**.
5. Double-tap **Security**.
6. Double-tap **Phone and SIM card**.
7. Double-tap **PIN code request**.
8. Double-tap **Off**.
9. Enter the PIN code. The default is **1234**.
10. Tap **OK**.

Change - Security code (aka lock code)

How to change the default security code

The phone requires the security code when you perform a master reset or a master clear. To change the default security code, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.
4. Double-tap **Phone mgmt**.
5. Double-tap **Security**.
6. Tap **Phone and SIM card**.
7. Double-tap **Lock code**.
8. Enter the lock code.
9. Tap **OK**.
10. Enter the new lock code.
11. Tap **OK**.
12. Re-enter the new lock code to confirm.
13. Tap **OK**.

Lock – Application lock

We're sorry, but this feature is not available on your particular phone model.

Lock – Keypad

How to lock and unlock the keypad

6

Locking the keypad protects against accidental key presses. No password is required to unlock the keypad. To lock and unlock the keypad, follow these steps:

Manual keypad lock

1. To lock the keypad, pull down the **Lock** key on the right side of the phone.
2. To unlock the keypad, pull down the **Lock** key again.

Automatic keypad lock

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.
4. Double-tap **Phone mgmt**.
5. Tap **auto. keyguard**.
6. Tap **Keypad autolock period**.
7. Tap **User defined**.
8. Tap the **Lock keypad after (minutes: seconds) field**.
9. Enter the duration.
10. Tap the **Checkmark** icon.
11. Tap **OK**.

Lock - Phone

How to turn on or turn off the phone lock

Phone lock causes the phone to lock when you turn it off. When you turn the phone back on, you must enter a password. To turn on or turn off the phone lock, follow these steps:

To lock

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.
4. Double-tap **Phone mgmt**.
5. Double-tap **Security**.
6. Tap **Phone and SIM card**.
7. Double-tap **Phone autolock period**.
8. Tap **User defined**.
9. Tap the **Lock after (minutes) field**.
10. Enter the duration.
11. Tap the **Checkmark** icon.
12. Tap **OK**.
13. Enter the lock code. The default is **12345**.
14. Tap **OK**.

To unlock

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Double-tap **Phone**.
4. Double-tap **Phone mgmt**.
5. Double-tap **Security**.
6. Tap **Phone and SIM card**.
7. Double-tap **Phone autolock period**.
8. Tap **None**.
9. Tap **OK**.
10. Enter the lock code. The default is **12345**.
11. Tap **OK**.

Unblock - PIN (PUK Code)

How to enter a PUK code

Related errors:

- 'PIN code blocked. Enter PUK code:'
- 'Enter PUK code'

If you enter the PIN code incorrectly several times in a row, the phone blocks you from attempting again. To enter a PUK code and unblock the PIN follow these steps:

6

Important: You must call T-Mobile Customer Care for the PUK code. Entering the wrong code can permanently damage your SIM card.

1. [Contact us](#) to request your PUK code.
2. Enter the PUK.
3. Tap **OK**.
4. Type a PIN of your choice.
5. Tap **OK**.
6. When **Confirm New PIN** message displays, re-enter the **PIN** code.
7. Tap **OK**.

Unblock - SIM (SIM subsidy unlock)

How to enter a SIM subsidy unlock code

Related errors:

- 'Enter Special Code'
- 'Please Wait to Enter Special Code'

The SIM subsidy unlock code allows the phone to use a SIM card from another wireless carrier. To enter the SIM subsidy unlock code, follow these steps:

Important: Stop if you receive an error message while performing the instructions below. The phone locks permanently if you enter the incorrect code multiple times.

1. From the Home screen, tap the **Dialer** icon.
2. Tap **#**.
3. Tap * three times. You will see **#p** on the display.
4. Tap * four times. You will see **#pw** on the display.
5. Tap * twice. You will see **#pw+** on the display.
6. Enter the unlock code.
7. Tap * twice. You will now see **#pw+unlock code+** on the display.
8. Tap **1**.
9. Tap **#**. The phone is now unlocked.

[Back to top](#)

Time and date

Alarm clock - Set

How to set the alarm clock

To set the alarm clock, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Applications**.
3. Tap **Clock**.
4. Tap **New alarm**.
5. Tap the **Alarm time** field.
6. Enter the time.
7. Tap the **Checkmark** icon.
8. Double-tap the **Description** field if needed.
9. Enter the desired name.
10. Tap the **Checkmark** icon.
11. Double-tap the **Repeat** field.
12. Double-tap one of the following:
 - **Not repeated**
 - **Within 24hrs**
 - **Daily**
 - **Workdays**
 - **Weekly**
13. Tap **Done**.

Auto-update (NITZ)

How to turn on or turn off automatic update of time and date (NITZ)

Automatic update of time and date (NITZ) checks for the correct time while the phone turns on. To turn on or turn off NITZ, follow these steps:

Note: When you enter a different time zone and turn on your phone, it automatically updates to the new time. This feature is network-dependent and may not be available in all areas.

1. From the Home screen, press the **Menu** key.
2. Tap **Applications**.
3. Tap **Clock**.
4. Tap **Options**.
5. Tap **Settings**.
6. Double-tap **Automatic time update** to turn on or off.
7. Tap **Yes**.

Time / date - Set

How to set or change the time and date

To set the time and date, follow these steps:

1. From the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Tap **Phone**.
4. Tap **Date and time**.
5. Double-tap **Time**.
6. Tap **Yes** to disable automatic time update if prompted.
7. Double-tap the **Time** field to open the keyboard.
8. Enter the time.
9. Tap the **Checkmark** icon.
10. Tap **OK**.
11. Tap **Yes** or **No** when the phone asks whether or not you have to travel to another time zone.
12. Double-tap **Date**.
13. Tap the **Date** field to open the keyboard.
14. Enter the date.
15. Tap the **Checkmark** icon.
16. Tap **OK**.

[Back to top](#)

DOC-3838

12900 Affichages Catégories: Settings & operating system

Tags: [reset](#) , [security](#) , [unlock](#) , [nokia](#) , [nuron](#) , [5230](#) , [backlight](#) , [time](#) , [settings](#) , [sim](#) , [date](#) , [language](#) , [subsidy](#)

Classement moyen d'un utilisateur

(0 classements)

0 Commentaires

Il n'y a aucun commentaire sur ce document.

CHECK COVERAGE See how we've got you covered
GET FREE SHIPPING See details

Phones

All Phones
4G Phones
Android Phones
Windows Phones
Smartphones
Refurbished Devices
Deals & Packages
Bring Your Own Device
Add A Line
Upgrade

Tablets

[All Tablets](#)

Internet Devices

[All Internet Devices](#)[Laptop Sticks](#)[Mobile HotSpots](#)[Pay In Advance Internet Devices](#)[Add A Line](#)

Plans

[All Plans](#)[Individual Plans](#)[Family Plans](#)[Tablets & Mobile Broadband Plans](#)[Bring Your Own Phone](#)[Add A Line](#)

Accessories

[All Accessories](#)[Batteries](#)[Bluetooth®](#)[Cases](#)[Chargers](#)[Headsets](#)[Memory Cards](#)

Services

[All Services](#)[Internet & Email](#)[International](#)[Messaging](#)[Music & Sounds](#)[Premium Handset Protection®](#)[Trade-In Program](#)[Activate a T-Mobile Phone](#)[Bring Your T-Mobile Account](#)[Check Your Status](#)[T-Mobile Retail Store Locations](#)[Return Policy](#)[HotSpot](#)[Rebates](#)[Puerto Rico](#)[JOIN US](#)[Facebook Twitter Youtube Google+](#)[Company:](#)[About T-Mobile](#)[Jobs](#)[Press](#)[Investor Relations](#)[Deutsche Telekom](#)[International](#)[Contact Us](#)[T-Mobile For:](#)[Developers](#)[Retailers](#)[Real Estate](#)[Affiliates](#)[Privacy Policy](#)[Privacy Resources](#)[Consumer information](#)[Public Safety/911](#)[Terms & Conditions](#)[Terms of Use](#)[Accessibility](#)[©2002-2013 T-Mobile USA, Inc.](#)